



# 100kW Loadbank with Baseload



# Rugged Build

Made of high quality material to withstand the elements.

### Weather Protected

Designed for outdoor use, weather protected, powder coated rigid IP55 construction.

## **Load Switching**

25kW automatic switching resolution.

# Longevity

Stainless steel enclosed elements consisting of 80/20 nickel chrome resistance wire for long service life.



### Reliability

12 months warranty.

### LOADBANK SPECIFICATIONS

#### Capacity

240/415V, 50 Hz, 1.0 PF.

#### **Design Voltage**

415 volts, 50 Hz Other voltages and frequencies available on request.

#### **Dimensions**

1276mm (h) X 1048mm (l) X 875mm (w) 230 KG Approx.

#### Cooling

One fan, forced air cooling. Comes with electrical interlocking system and Thermal sensors for safe operations.

#### Resistors

Load is provided by groups of totally enclosed resistor elements consisting of 80/20 nickel chrome resistance wire centred in a finned stainless steel tube filled with compressed magnesium oxide to ensure rapid heat transfer.

Air Flow

3,000 CFM, designed for the outdoors.

#### **Parameters**

Maintains maximum capacity in ambient conditions up to 40° C and 100% humidity.

VIC Office: 136 Fairbank Road, Clayton South, VIC 3169 Tel.: 03 9544 4222 Fax: 03 9543 7138 NSW Office: 1 St James Place, Seven Hills, NSW 2147 Tel.: 02 9899 6699 Fax: 02 9899 8048 QLD Office: 31 South Pine Road, Brendale, QLD 4500 Tel.: 07 3205 6333 Fax: 07 3205 6344


Power Anywhere, Anytime 1300 MAC GEN (622 436)







# 100kW Loadbank with Baseload



### **Baseload Control**

Baseload is a lower cost system which ensures that a generator never runs below a minimum loading level. Load is switched in single steps by contactors controlled by a PCB monitoring the 5 amp secondary of a current transformer, installed on L1 of the customer's distribution cables. When the site load falls below a preset level, the contactors close

connecting the load to the generator in sequential 25kW steps up to a maximum of 4 steps. The controller continues to monitor the total load and when it has risen above a preset value the contactors will open removing the dummy load from the generator in stages. When specified a two stage controller can be fitted to switch the load in two equal steps.

Note: 1. CT is excluded and must be supplied and installed by the customer.

2. Materials and specifications are subject to change without notice.

**VIC Office:** 136 Fairbank Road, Clayton South, VIC 3169 Tel.: 03 9544 4222 Fax: 03 9543 7138 **NSW Office:** 1 St James Place, Seven Hills, NSW 2147 Tel.: 02 9899 6699 Fax: 02 9899 8048 **QLD Office:** 31 South Pine Road, Brendale, QLD 4500 Tel.: 07 3205 6333 Fax: 07 3205 6344

Power Anywhere, Anytime 1300 MAC GEN (622 436)

