


RC300-3000


For 3000/3600 RPM **Generator Set**

ESTABLISHED 1949


MELBOURNE | SYDNEY | BRISBANE




EASY OPERATION INSTRUCTION REMOTE CONTROLLER




Plug to ATS socket



Switch to AUTO/ATS position



Push F to N to turn remote control ON



Push ON to activate Start cycle. Push OFF to activate Stop and Cooldown cycle.

For use on any ITC/KOMPAK Diesel Generator or most other 2-wire Start Generators. Working distance of inline sight up to 150 meters.