





# 1700 Running Watts<sup>1</sup> 2200 Starting Watts<sup>2</sup>



Model	P2200
Part Number	PN: 030697
Number Of Outlets	3
Engine	OHV
Displacement	111 cc
Horsepower**	
Amperage	15A
Voltage	230V AC
Auto Idle	Yes

Auto Voltage Regulation	Inverter
Fuel Tank Capacity (L)	3.7
Muffler	Yes - Spark Arrestor Type
Weight (Kg)	24 kg
Low Oil Protection System	Yes
RCD	No
Dimensions L x W x H (cm)	53x36x43
Warranty* Domestic	3 Years Limited
Warranty* Commercial	1 Year Limited

### **Manoeuvrability**

Easy Portability with 2-person H-Beam Carry Handle

- 2200 watts peak / 1700 watts continuous
- 12v 5amp outlet with extra USB adapter. Easier connection of USB devices
- Parallel Kit Socket Utilizing the B&S Parallel Kit (p/n 6330) you can join a 2200 with another 2200 or a 3000 to increase power output
- Overload alarm, circuit breaker and low oil protection

<sup>1.</sup> Per CSA C22.2 No. 100-14 and ANSI/PGMA G300-2015. 2. Starting Watts is the maximum current that can momentarily be supplied when starting a motor, multiplied by the generator's rated voltage. \* Terms and conditions apply see owners manual for details. \*\*All power levels are stated gross horsepower per SAE J1940 as rated by Briggs & Stratton.







# **2600** Running Watts<sup>1</sup> **3000** Starting Watts<sup>2</sup>



Model	P3000
Part Number	PN: 030654
Number Of Outlets	3
Engine	OHV
Displacement	171cc
Horsepower**	
Amperage	15A
Voltage	230V AC
Auto Idle	Yes

Auto Voltage Regulation	Inverter
Fuel Tank Capacity (L)	5.7
Muffler	Yes - Spark Arrestor Type
Weight (Kg)	44 kg
Low Oil Protection System	Yes
RCD	No
Dimensions L x W x H (cm)	66x36x53
Warranty* Domestic	3 Years Limited
Warranty* Commercial	1 Year Limited

# Manoeuvrability

- Easy Portability with 2-person H-Beam Carry Handle
- Retractable handles and wheels making it easy to move

- Statstation™ Digital Display Displays power usage, total unit lifetime hours, and maintenance reminders.
- Pull Start
- USB Charging Port
- Parallel connector port double your power output (Optional kit to join two sets together)

<sup>1.</sup> Per CSA C22.2 No. 100-14 and ANSI/PGMA G300-2015. 2. Starting Watts is the maximum current that can momentarily be supplied when starting a motor, multiplied by the generator's rated voltage. \* Terms and conditions apply see owners manual for details. \*\*All power levels are stated gross horsepower per SAE J1940 as rated by Briggs & Stratton.







# **2500** Running Watts<sup>1</sup> **3125** Starting Watts<sup>2</sup>



Model	3200A
Part Number	PN: 030695
Number Of Outlets	2
Engine	Briggs & Stratton®
Displacement	196cc
Horsepower**	
Amperage	15A
Voltage	230V AC
Auto Idle	

Auto Voltage Regulation	Yes
Fuel Tank Capacity (L)	11.4L
Muffler	Lo-Tone™
Weight (Kg)	50 kg
Low Oil Protection System	No
RCD	
Dimensions L x W x H (cm)	63x55x53
Warranty* Domestic	2 Years Limited
Warranty* Commercial	

# Manoeuvrability

- Collapsible handle
- Never-Flat wheels

# **Strength & Rigidity**

- Weld free tube frame for a stronger build
- Engine mounted to frame through high tension rubber engine mounts for reduced vibration
- Durable steel fuel tank with fuel gauge

- The Power Surge<sup>™</sup> Alternator produces a short surge of power needed to start large motor-driven appliances and tools simultaneously.
- Pull Start
- 2 x IP44 Water resistant sockets with 12 Volt/5A Auxiliary power outlet
- Automatic Voltage Regulator Limits the variation of the voltage of your generator to +/- 2% to keep your equipment running smoothly and safely.

<sup>1.</sup> Per CSA C22.2 No. 100-14 and ANSI/PGMA G300-2015. 2. Starting Watts is the maximum current that can momentarily be supplied when starting a motor, multiplied by the generator's rated voltage. \* Terms and conditions apply see owners manual for details. \*\*All power levels are stated gross horsepower per SAE J1940 as rated by Briggs & Stratton.







# **7000** Running Watts<sup>1</sup> **9500** Starting Watts<sup>2</sup>



Model	Elite 9500/7000
Part Number	PN: 030724
Number Of Outlets	2
Engine	Briggs & Stratton 2100 Series
Displacement	420cc
Horsepower**	13.5
Amperage	32A
Voltage	230V AC
Auto Idle	Yes

Auto Voltage Regulation	Yes
Fuel Tank Capacity (L)	28
Muffler	Yes - Spark Arrestor Type
Weight (Kg)	104 kg
Low Oil Protection System	Yes
RCD	Yes
Dimensions L x W x H (cm)	72x54x63
Warranty* Domestic	2 Years Limited
Warranty* Commercial	1 Year Limited

### **Manoeuvrability**

- T-Style collapsible padded handle
- Never-Flat wheels
- Heavy duty roll-frame suits any worksite

# **Strength & Rigidity**

- 38mm thick, weld free tube frame for a stronger build
- Engine mounted to frame through high tension rubber engine mounts for reduced vibration
- Durable steel fuel tank with fuel gauge

- Statstation™ Digital Display Displays power usage, total unit lifetime hours, and maintenance reminders.
- Electric Start for easy ignition
- 2 x IP66 Water resistant sockets
- Automatic Voltage Regulator and 32A Circuit Breaker

<sup>1.</sup> Per CSA C22.2 No. 100-14 and ANSI/PGMA G300-2015. 2. Starting Watts is the maximum current that can momentarily be supplied when starting a motor, multiplied by the generator's rated voltage. \* Terms and conditions apply see owners manual for details. \*\*All power levels are stated gross horsepower per SAE J1940 as rated by Briggs & Stratton.